



Two-Tone Pull Installation

Place knob or pull in desired position on cabinet and mark holes to be drilled.

Before drilling make sure to take into account that the holes in the post are 5/16" off the center of the knob/pull. See diagram for clarification.